

# Demounting a Truck Body

## Prepare to Demount a Body

1. Put the truck in neutral and set the parking brake.
2. Turn on the power cut-off switch on the cab floor

***For liftgate-equipped vehicles – unlock and lower liftgate to clear body longrails.***

### UNLOCKING THE TRUCK BODY

1. Remove lock key.



2. Push yellow safety pin handle in to unlock pin.



3. Push the large black locking handle down.



### NOTE

Cab-mounted safety buzzer/light will activate. This indicator will continue until a body is properly locked onto the truck chassis.

### DISCONNECTING THE LIGHT PLUG

1. Disconnect light plug from body.



2. Insert plug into the light plug holder.



## LIFTING MOUNTED TRUCK BODY

1. Push the "UP" power control button in to lift the system.



2. Lift the body to a height that when it is lowered it will stand at your desired loading height (there needs to be approximately two (2) inches of clearance between the lifting frame and the standing body).

**NEVER DRIVE WITH THE BODY ELEVATED OR UNLOCKED!**

## SETTING THE LEGS

1. Wear gloves for hand protection.
2. Unlock and remove chained pin from the foot of leg under the body side rail.



3. With fingers under the footpad, pull the leg out all the way and lower to the vertical position.



4. Adjust the lower leg (inner) as close to the ground as possible and pin it at that height.



5. Put chained pin through upper stabilizing brace & leg.



6. Push leg assembly into the body leg housing until brace touches the truck body.



7. Check that all pins are secured into the proper position.



### LOWERING THE LIFTING FRAME

1. With all four legs set and pinned securely, the lifting frame can be lowered.



2. Push the "DOWN" power control button in to lower the lifting frame back to the truck chassis.



3. Lower the lifting frame until a squealing sound is heard. This indicates that the lift is fully lowered.

### PULLING OUT FROM A STANDING BODY

1. Release parking brake.
2. Pull truck forward slowly.
3. Be sure to pull out straight at least the length of the truck body.

#### NOTE

If the truck chassis is equipped with a liftgate, be sure the gate clears the standing body. This requires lowering the liftgate before pulling forward.