

NOTE:
ALL 16 Ga. WIRE

Run the black and white wires in the 16/2 cable from the cab (from DLK-291) in through the 1/2" watertight connector at the rear of the pump box. Connect these wires as shown. White to position 1 and black to position 7.


Run the black and white wires in the 16/2 cable from the "A" frame switch (from DLK-423). White to position 1 and black to position 7.

Run the 16/4 cable from the control box (from DLK-423). Black to position 1, white to position 2, red to position 3 and green to position 4. Position 5 and 6 to remain empty.

Be sure all connections are secure. Check for proper connections by turning on the ignition key. Unlock the Chassis Lift, push in on the yellow handle and push the big black bar down. The alarm in the cab should turn on. When the system is locked, the alarm should turn off.

Secure the junction box.

COPYRIGHT 2001 DEMOUNTABLE CONCEPTS, INC.
THIS DRAWING AND THE DATA SHOWN IS PROPRIETARY AND CONFIDENTIAL. DO NOT USE OR REPRODUCE FOR ANY PURPOSE WITHOUT THE WRITTEN CONSENT OF DEMOUNTABLE CONCEPTS, INC.

| | | | |
|---|------------------|---------------------|--------------|
|  DEMOUNTABLE CONCEPTS, INC. | | | |
| FINAL CONTROL WIRING CONNECTIONS CHASSIS LIFT FOR: | | | |
| SIZE A | REV. NO. 0 | PART NO. DLK-425 | |
| DRAWN KEVIN PERKINS | DATE 12/28/01 | JOB NO. 2150 | |
| SCALE | CAD# DLK-425 | | SHEET 1 OF 1 |